

WTC 409A.18  
DRAWING NUMBER  
511690  
2-25

DRAWING NUMBER

DRAWING NUMBER

WTC 409A.18  
DRAWING NUMBER  
511690  
2-25

SMOKE DETECTION PANEL XL No. 10 SCHEDULE 'B' (DUAL ADDRESS INPUTS)								
INPUT			OUTPUT				REMARKS	
ADDRESS No. 1	ADDRESS No. 2	INITIATING DEVICES	RESULTING ADDRESS	ANNUNCIATOR MESSAGES	ACTIVATED RELAYS	ACTIVATED HVAC EQUIPMENT		
101104	101105	POX-31-131 INTERFACE MODULE TRX-2R-6-7	101130	SOL VALVE DUMP 75 EAST TWR 2	SPX-14-023 GROUP A	SOL. VALVE DUMP ACS-75-3 GROUP A		
101104	101106							
101107	101108				SPX-17-051 GROUP A	SOL. VALVE DUMP ACS-75-12 GROUP A		
101109	101110				SPX-16-041 GROUP A	SOL. VALVE DUMP ACS-75-8 GROUP A		
101201	101202				SPX-14-022 GROUP A	SOL. VALVE DUMP ACS-75-2 GROUP A		
101201	101203							
101204	101205				SPX-16-044 GROUP A	SOL. VALVE DUMP ACS-75-11 GROUP A		
101206	101207				SPX-15-034 GROUP A	SOL. VALVE DUMP ACS-75-7 GROUP A		
101208	101209				SPX-17-053 GROUP A	SOL. VALVE DUMP ACS-75-14 GROUP A		
101210	101211				SPX-18-061 GROUP A	SOL. VALVE DUMP ACS-75-16 GROUP A		
				GROUP A	POX-25-073 POX-25-074 POX-26-081 POX-26-082 POX-26-083 POX-26-084 POX-19-013 POX-19-014 POX-20-024 POX-21-031 POX-21-034 POX-22-041 POX-22-043 POX-23-051	RETURN AIR FAN ACR-75-7 SHUTDOWN RETURN AIR FAN ACR-75-8 RETURN AIR FAN ACR-75-9 RETURN AIR FAN ACR-75-10 RETURN AIR FAN ACR-75-11 RETURN AIR FAN ACR-75-12 SUPPLY FAN ACS-75-2 SUPPLY FAN ACS-75-3 SUPPLY FAN ACS-75-7 SUPPLY FAN ACS-75-8 SUPPLY FAN ACS-75-11 SUPPLY FAN ACS-75-12 SUPPLY FAN ACS-75-14 SUPPLY FAN ACS-75-16		
101111	101112	POX-31-133 INTERFACE MODULE TRX-2R-6-9	101129	SOL VALVE ACS-75-17 TWR 1	SPX-18-062	SOL. VALVE DUMP ACS-75-17		

SMOKE DETECTION PANEL XL No. 10				
INPUT			RESULTING ADDRESS	ANNUNCIATOR MESSAGES
ADDRESS No. 1	ADDRESS No. 2	INITIATING DEVICES		
101301	101302	POX-31-132 INTERFACE MODULE TRX-2R-6-8	101330	SOL VALVE 75 TWR
101303	101304			
101305	101306			
101307	101308			
101309	101310			
101309	101311			
101401	101402			
101403	101404			
101405	101406			
101405	101407			